



PO Box 727, 195 Third Street South  
Dassel, MN 55325  
Phone: 800-328-8909  
Fax: 800-369-9207  
Email: [customerservice@cresthealthcare.com](mailto:customerservice@cresthealthcare.com)

This workbook contains IR codes for Crest Excel EntertainIR (XR) and Remote Call-IR (XP) devices. Please refer to the appropriate worksheet for the device and type of equipment (TV, DVD or VCR) you would like to use. Note that Excel EntertainIR uses three-digit IR codes and Remote Call-IR uses 4-digit IR codes.

The Excel EntertainIR or Remote Call-IR can be programmed to accept any of the codes to work with the equipment listed on the appropriate worksheet. For many manufacturers, more than one code is listed. In these cases, it is recommended that you program your device for the first code and test the functionality of each button. If any button does not function as intended, program the device for the next code on the list and test again. If none of the codes on the list give you the functionality you require, contact the Technical Support Department at Crest about custom programming options. TV manufacturers are continually adding new codes that may or may not be referenced in this document. Also, depending on the date your device was manufactured, certain codes on this list may not be included in the board within your device. If this is the case, contact Crest about pricing for board upgrades.



TV	Fisher	007	010	031						
TV	Fujitsu	015								
TV	Funai	015	019	021	055					
TV	Futuretech	019								
TV	GE	000	004	016	018	021	023			
TV	Gibraltar	001	004							
TV	Goldstar	004	020							
TV	Gradiente	004								
TV	Grunpy	015	019							
TV	Hallmark	004								
TV	Harley Davidson	015								
TV	Harman/Kardon	002	003	004	014	024				
TV	Harvard	019								
TV	HCI	006	030	050						
TV	Hitachi	004	005	022	023	063				
TV	Infinity	002	003	014	024					
TV	Inovision	000	016							
TV	Insignia	035								
TV	Inteq	001								
TV	JBL	002	003	014	024					
TV	JC Penney	000	004	007	010	018	020	023		
TV	Jensen	004								
TV	JVC	018								
TV	Kawasko	004								
TV	KEC	019								
TV	Kenwood	004								
TV	Kloss Novabeam	019								
TV	Konka	015								
TV	KTV	004	019	021						
TV	LG	001	004	005	020					
TV	Lloyds	004								
TV	Loewe	002	003	014						
TV	Logik	005								
TV	Luxman	004								
TV	LXI	000	002	003	004	007	010	014	023	024
TV	Magnasonic	004	022							
TV	Magnavox	002	003	004	014	015	024	037	040	
TV	Majestic	005								
TV	Marantz	002	003	004	014	024				
TV	Matsushita	008	013							
TV	Megatron	004								
TV	Memorex	004	005	008	013	015	020			
TV	MGA	004	020							
TV	Midland	000	001							
TV	Mitsubishi	004	020							
TV	Montgomery Ward	005								
TV	Motorola	011								
TV	MTC	002	003	004	014	018	020	022		
TV	Multitech	019								
TV	NAD	004	007	010						
TV	NEC	004	020							
TV	Nikko	004	022							



TV	Totevision	023											
TV	Ultra	022											
TV	Vector Research	004											
TV	Video Concepts	021											
TV	Vidikron	002	003	014	024								
TV	Vidtech	004											
TV	ViewSonic	029	035	040	042								
TV	Viore	066											
TV	Vistek	018											
TV	Vizio	048	060										
TV	Wards	000	002	003	004	005	014	015	018	020	023	024	
TV	Waycon	007	010										
TV	White Westinghouse	004	016	022	038								
TV	Yamaha	004	020	022									
TV	Zenith	001	004	005	022	039							

## DVD CODE LIST

<u>DEVICE</u>	<u>BRAND</u>	<u>CODES</u>			
DVD	Coby	021			
DVD	GE	001			
DVD	HCI	012	014		
DVD	Hitachi	008			
DVD	Ipod Soundworks	031			
DVD	KEC	005			
DVD	LG	000			
DVD	Magnavox	003			
DVD	Modular Cyber Home	018			
DVD	Onkyo	003			
DVD	Panasonic	004	017		
DVD	PDI	015	016	023	024 (modular)
DVD	Philips	003	009	028	32
DVD	Proscan	001			
DVD	RCA	001	029	030	
DVD	RC-1002N	019			
DVD	Samsung	008	025		
DVD	Sharp	022			
DVD	Sony	002	006	007	
DVD	Sylvania	010	026		
DVD	Toshiba	003	011	013	
DVD	View Sonic	020			
DVD	Viore	033			
DVD	Zenith	000	003		

## VCR CODE LIST

<u>DEVICE</u>	<u>BRAND</u>	<u>CODES</u>
VCR	Aiwa	000
VCR	American High	008
VCR	Asha	006
VCR	Audiovox	000
VCR	Beaumarck	006
VCR	Calix	000
VCR	Canon	008
VCR	Citizen	000 006
VCR	Craig	000 006
VCR	Curtis Mathes	001 004 005 006 008
VCR	Cybernex	006
VCR	Dimensia	001
VCR	Electrohome	000
VCR	Electroponic	000
VCR	Emerson	000 008
VCR	Fuji	008
VCR	GE	001 006 008
VCR	Go Video	006
VCR	Goldstar	000 006
VCR	JC Penney	000 006 008
VCR	KEC	000
VCR	Kodak	000 008
VCR	LG	000
VCR	LXI	000
VCR	Magnavox	008
VCR	Magnin	006
VCR	Marantz	008
VCR	Marta	000
VCR	Matsushita	004 005 008
VCR	MEI	008
VCR	Memorex	000 004 005 006 008
VCR	MGA	006
VCR	MGN	006
VCR	Motorola	008
VCR	MTC	006
VCR	Multitech	006
VCR	Nikko	000
VCR	Noblex	006
VCR	Olympus	008
VCR	Optimus	000 004 005 006
VCR	Panasonic	004 005 008
VCR	Philco	008
VCR	Philips	008 009
VCR	Pilot	000
VCR	Profitronic	006
VCR	Proscan	001
VCR	Quasar	004 005 008
VCR	RadioShack	000 006
VCR	RadioShack/Realistic	000 006 008

VCR	Radix	000			
VCR	Randex	000			
VCR	RCA	001	006	008	
VCR	Realistic	008			
VCR	Samsung	006	012		
VCR	Sanyo	006			
VCR	Sears	000	008		
VCR	Shogun	006			
VCR	Singer	008			
VCR	Sony	002	007	008	
VCR	STS	008			
VCR	Sylvania	008	011		
VCR	Tashiko	000			
VCR	Technics	004	005	008	
VCR	Teknika	000	008		
VCR	TMK	006			
VCR	Toshiba	003	010		
VCR	Totevision	000	006		
VCR	Unitech	006			
VCR	Videomagic	000			
VCR	Videosonic	006			
VCR	Wards	000	001	006	008
VCR	XR-1000	008			
VCR	Zenith	000			

**STB CODE LIST**

DEVICE BRAND

CODES

VOD DVD VOD DVD

STB Comcast

006 007 008 009

STB Direct TV(Mayo)

004 005