



PO Box 727, 195 Third Street South
Dassel, MN 55325
Phone: 800-328-8908
Fax: 800-369-9207
Email: customerservice@cresthealthcare.com

This workbook contains IR codes for Crest Remote Call-IR (XP) devices. Please refer to the appropriate page for the device you would like to use. Note that Remote Call-IR uses 4-digit IR codes.

The Remote Call-IR can be programmed to accept any of the codes to work with the equipment listed on the appropriate page. For many manufacturers, more than one code is listed. In these cases, it is recommended that you program your device for the first code and test the functionality of each button. If any button does not function as intended, program the device for the next code on the list and test again. If none of the codes on the list give you the functionality you require, contact the Technical Support Department at Crest about custom programming options. TV manufacturers are continually adding new codes that may or may not be referenced in this document. Also, depending on the date your device was manufactured, certain codes on this list may not be included in the board within your device. If this is the case, contact Crest about pricing for board upgrades.

Code Library
© Crest Healthcare Supply, 2011

August 30, 2011
62

TV CODE LIST

<u>DEVICE</u>	<u>BRAND</u>	<u>CODES</u>
TV	Action	0103
TV	Admiral	0002 0003 0011 0032 0113
TV	Aiko	0112
TV	Akai	0010
TV	Alaron	0033
TV	American Action	0103
TV	Amtron	0103
TV	Anam	0103 0111
TV	Anam National	0103

TV	Fujitsu	0033								
TV	Funai	0033	0103	0111	0313					
TV	Futuretech	0103								
TV	GE	0000	0010	0100	0102	0111	0113			
TV	Gibraltar	0001	0010							
TV	Goldstar	0010	0110							
TV	Gradiente	0010								
TV	Grunpy	0033	0103							
TV	Hallmark	0010								
TV	Harley Davidson	0033								
TV	Harman/Kardon	0002	0003	0010	0032	0120				
TV	Harvard	0103								
TV	HCI	0012	0132	0302	1022					
TV	Hitachi	0010	0011	0112	0113	0333				
TV	Infinity	0002	0003	0032	0120					
TV	Inovision	0000	0100							
TV	Insignia	0203								
TV	Inteq	0001								
TV	JBL	0002	0003	0032	0120					
TV	JC Penney	0000	0010	0013	0022	0102	0110	0113		
TV	Jensen	0010								
TV	JVC	0102	1011							
TV	Kawasko	0010								
TV	KEC	0103								
TV	Kenwood	0010								
TV	Kloss Novabeam	0103								
TV	Konka	0033								
TV	KTV	0010	0103	0111						
TV	LG	0001	0010	0011	0110	0320	1021			
TV	Lloyds	0010								
TV	Loewe	0002	0003	0032						
TV	Logik	0011								
TV	Luxman	0010								
TV	LXI	0000	0002	0003	0010	0013	0022	0032	0113	0120
TV	Magnasonic	0010	0112							
TV	Magnavox	0002	0003	0010	0032	0033	0120	0211	0220	
TV	Majestic	0011								
TV	Marantz	0002	0003	0010	0032	0120				
TV	Matsushita	0020	0031							
TV	Megatron	0010								
TV	Memorex	0010	0011	0020	0031	0033	0110			
TV	MGA	0010	0110							

