

Call Crest Technical Support for assistance at: **1-800-328-8908**

www.cresthealthcare.com ©2012 Crest Healthcare Supply



Patient Station Crest Replacement for Rauland[®]

BS-8500C

Function Table

Original Terminal Designation	1	2	3	4	5	6
Crest Replacement	Black	Red	N/A	Blue	Yellow	White

Typical Installation

- 1. The black wire is connected to the (-) 0V side of the power supply.
- 2. The red wire is connected to the (+) 12V side of the power supply.
- 3. The blue wire is normally connected to the corridor light.
- 4. The yellow wire is normally connected to the annunciator at the nurses station.
- 5. The white wire is connected to line A.

Electrical Schematic



ELECTRICAL

Current and Voltage Rating: 12VDC

MECHANICAL

Mounting: Fits standard single gang back box

SIZE MEASUREMENTS

Plate: 4.5" x 2.75" (1 Gang)

