



In-Line Audio Amplifier

P/N 114782



Specifications

ELECTRICAL

Current and Voltage Rating: 200mA @ 12VDC

MECHANICAL

Terminals: Wire Leads
Mounting: Screw to standard single gang wall box

SIZE MEASUREMENTS

Plate: Single Gang (2.75" X 4.5")

Typical Installation

1. Use the supplied wire nuts to connect the RED wire to the AUDIO lead from the patient station and the BLACK wire to the COMMON lead from the patient station.
2. Fasten the coaxial cable from the TV signal source to the "F" connector on the backside of the Amplifier plate.
3. Screw the amplifier unit to the wall box.
4. Fasten coaxial cable from the TV to the "F" connector on the front side of the amplifier plate.
5. Connect a 1/4" phone plug jumper cable (not included) to the headphone port on the TV.
6. Plug the power supply (included) into a 120V outlet and connect to the amplifier.
7. Power the TV on and turn the volume up to the maximum. If the volume is too soft or too loud call Technical Support for troubleshooting.

Drawing

