

NOVAERUS PORTABLES MAINTENANCE



VENT CLEANING

Use a vacuum to remove dust from side vents as needed.

You can also use damp cloth to wipe off the vents.

PRE-SCREEN CLEANING (NV900 ONLY)

The pre-screen for the NV900 is needed to prevent larger dust particles from clogging the fan. It is similar in nature to a lint trap on a clothes dryer. It can be found directly behind the front metal casing.

To clean the pre-screen, please follow these steps:

- 1 Reach into the open space behind the front metal casing to grasp the pull tab on the pre-screen.
- 2 Lift the pull tab directly up to expose the screen.
- 3 Vacuum or wipe down the screen with a damp cloth.
- 4 Slot the pre-screen back into place with the metal grid facing the unit.

