

RCA COMMERCIAL SERIES TELEVISION FEATURE OVERVIEW

CLONING SETUP & OPERATION



Part 1 | Accessing the Commercial Menu (C.M.)

Each RCA Commercial Television has a Commercial Menu that is accessible only by using the TV programming remote. Follow the steps below to access the C.M. for the RCA BE Series TV. *Programming remote not included with TVs, contact customer support for a programming remote.*

- | For the RCA BE Series television, use the programming remote **R230D2**.
- | Press the **'Menu'** button
- | Go to the **'Parental Tab'** section of the menu.
- | Enter the passcode **0-0-0-0**
- | Enter the **'Commercial Menu'**

Part 2 | Using the Clone Feature

Before cloning TV settings plug a USB 2.0 or higher, with at least 500 MB of storage into the back of the TV.

- | Access the **Commercial Menu** using the TV Programming Remote
- | Choose the **TV to USB** function, which exports clone settings to the USB.
- | A successful Clone Out will prompt an **'Export Success'**.
- | Remove the USB from the TV, and place it into the TV you want to clone settings to.
- | Repeat step 1, access the **Commercial Menu** using the TV Programming Remote
- | Choose the **USB to TV** function, this imports clone settings from the USB to the TV.
- | When done correctly the TV will restart. Cloning is now complete.

BE Programming Remote



Programming remote for LV & BE Series Televisions.

- | **Part Number R230D2**
- | **Not Included with TV. Contact Support**

Contact Support

Toll Free Phone
1-800-722-2161 opt. 1
Tech support answered by humans

Email
support@rcacommercialtv.com
Tech support answered by humans

Corporate HQ
5935 W. 84th Street, Suite A
Indianapolis, IN 46278