

# RCA LODGING SERIES TELEVISION FEATURE OVERVIEW

## CLONING SETUP & OPERATION



### Part 1 | Accessing the Commercial Interace Menu (C.I.M.)

Each RCA Commercial Television has a Commercial Interace Menu that is accessible only by using the TV programming remote. Follow the steps below to access the C.I.M. for the RCA LV Series TV. *Programming remote not included with TVs, contact customer support for a programming remote.*

- | For the RCA LV Series television, use the programming remote **R230D2**.
- | Press the **'Menu'** button
- | Go to the **'Option'** section of the menu.
- | Enter the **'Customer Interface Menu'**

### Part 2 | Using the Clone Feature

Before cloning TV settings plug a USB 2.0 or higher, with at least 500 MB of storage into the back of the TV.

- | Access the **Commercial Interface Menu** using the TV Programming Remote
- | Select **Clone Management** function in the Commercial Interface Menu.
- | Choose the **Clone Out** function, which exports clone settings to the USB.
- | A successful Clone Out will prompt an **'OK'**.
- | Remove the USB from the TV, and place it into the TV you want to clone settings to.
- | Repeat steps 2 & 3. (Access the C.I.M. and select Clone Management)
- | Choose the **Clone In** function, this imports clone settings from the USB to the TV.
- | When done correctly the TV will restart. Cloning is now complete.

### LV Programming Remote



Programming remote for LV & BE Series Televisions.

- | **Part Number R230D2**
- | **Not Included with TV. Contact Support**

### Contact Support

**Toll Free Phone**  
1-800-722-2161 opt. 1  
Tech support answered by humans

**Email**  
support@rcacommercialtv.com  
Tech support answered by humans

**Corporate HQ**  
5935 W. 84<sup>th</sup> Street, Suite A  
Indianapolis, IN 46278