

Corridor Pilot Light with Sounder

P/N 115452-1 & 115452-2

The Crest 115452 Corridor Pilot Light with Sounder consists of a white plastic wedge shaped dome and a sounder mounted on a single-gang or dual-gang stainless steel plate. The product comes with one lamp, one lamp socket with pigtail wires and the sounder, which is panel-mounted onto the plate. The dome is held to the plate with two screws and can be easily removed for relamping. Colored filters are available upon request.



115452-2



115452-1

Installation

The dome lens, lamps, sockets, sounder and pigtails are mounted on a stainless steel single-gang or dual-gang wall plate. Electrical connections are made to the lamp sockets using pre-wired pigtail wires. The stainless steel wall plate is fastened directly to the electrical back box. The sounder has (+) and (-) marking on the bottom. Ensure that the sounder is connected appropriately.

Specifications

ELECTRICAL

Lamp Voltage Rating:	28 VAC/DC
Sounder Voltage Rating:	16-25 VAC/DC
Sounder Current Rating:	15 mA

MECHANICAL

Lamps:	Miniature bayonet type (#313)
Mounting:	Fits standard single-gang or dual-gang electrical back box
Sounder & Lamp Terminal:	2 Pigtail wires (each)

SIZE MEASUREMENTS

Plate:	2.75"W x 4.5"H (single-gang) 4.562"W x 4.5"H (dual-gang)
White Lens (B-31695):	2.25"W x 4"H x 3.125"D