




# Quam UL22JB


UL22JB is a shallow depth, lightweight, UL listed fire signaling device and high efficiency loudspeaker. It features a built-in junction box for mass notification & emergency communications devices and provides superior voice intelligibility packaged in a complete, 2' x 2' loudspeaker assembly. Components include: an 8" O.D., fire retardant loudspeaker with a 10 oz. magnet and a 4W, 25/70V rotary select transformer and integral junction box for secure and inspectable connections. The integral enclosure is 1,283 CID, molded fiber. The grille is perforated steel with four (4) seismic tie-off points in a white powder coat finish. A line supervision capacitor is included. No assembly required.



<b>APPLICATION</b>	<b>Intended Use:</b> <b>Program Material:</b> <b>Installation:</b>	Mass notification and emergency communications Signal tones and voice Fits into a 2' x 2' or 2' x 4' wide ceiling tile grid
<b>AUDIO PERFORMANCE</b>	<b>Average Sensitivity</b> <b>Sound Pressure dB-SPL @10' per Tap:</b> <b>Loudspeaker Power Rating:</b> <b>Magnet Type &amp; Weight:</b> <b>Frequency Response:</b> <b>Nominal Coverage Angle:</b> <b>Audio Connection:</b>	1/4W = 78.7dB, 1/2 = 80.7, 1 = 81.5, 2 = 84.3, 4 = 87.4 20W RMS, EIA 426A Standard BeFe Ceramic, 10 oz. Nominal 60Hz - 17kHz, EIA 426A Standard 100° Included Angle, -6dB/2kHz, Half space Dual Set of 6", Color-coded, Pre-cut and Tinned Leads
<b>COMPONENT</b>	<b>Dimension:</b> <b>Weight:</b> <b>Loudspeaker Model:</b> <b>Loudspeaker Specs:</b> <b>Transformer:</b> <b>Integral Enclosure:</b> <b>Grille:</b> <b>Finish:</b> <b>Additional Component(s):</b> <b>Other:</b>	3 1/2" (H) x 23 13/16" (W) x 23 13/16" (D) 9 lbs. 8C10PAFR 8" O.D. loudspeaker, 10 oz. magnet, fire retardant 4W, 25V (yellow) and 70V (red) rotary select with 5 taps (0.25W, 0.50W, 1W, 2W, 4W) 1,283 CID, molded fiber Perforated steel with four (4) seismic tie-off points White powder coat finish Integral junction box (4 square) A 10uF, 150V, line supervision capacitor is included
<b>CERTIFICATION</b>	<b>UL Listed 1480 (UUMW) TYPE F</b> <b>UL Listed 2043</b> <b>ASTM E84</b> <b>CSFM Certified #7320-2288:0500</b>	When installed with supplied installation instructions and requirements of NEC/AHJ Suitable for use in air-handling spaces Includes integral backbox that meets/exceeds flame and smoke test w/ 3hr. burn rating For use with separately listed compatible fire alarm control units
<b>ADDITIONAL MODELS</b>	<b>UL22</b> <b>UL22DM</b>	2' x 2' UL Listed Fire Signaling Device with 25/70V transformer 2' x 2' UL Listed Fire Signaling Device with 25/70V transformer, Built-In Device Mount



Speaker Tap Selector

Standard Perforation Pattern  
Shown as 1" Square Sample