

NV200 SPECIFICATIONS



Novaerus uses patented active purification technology to continuously pull contaminated indoor air across internal short-exposure plasma coils, deactivating airborne microorganisms and viruses at the DNA level.

MODEL

NOVAERUS NV200 Air Purifier Wall mountable, countertop or stand-alone unit supplied with 8.2 ft. power cord

ELECTRICAL RATING

120VAC, 60Hz, 0.08A Fuse rated at 125VAC, 3 amps, Listed Power consumption 20 watts

CONSTRUCTION + COLOR

Precision-cut fabricated metal casing with an off-white, powder coat finish

DIMENSIONS + WEIGHT

5.2" w x 11.1" h x 4.3" d 7.6 lb.

ELECTRICAL CONNECTION

Switched and fused with a grounded, molded 3 pin power cord

FAN AIR FLOW VOLUME 50 ft³/min

OPERATING CONDITIONS 10-35°C, 10-75% Relative Humidity, 2000m

SHIPPING / STORAGE CONDITIONS 5°C-50°C, Maximum 95% Relative Humidity

QUALITY + SAFETY Manufactured under ISO 9001, ISO 14001 and OHSAS 18001



35 Melrose Place | Stamford | CT 06902 | USA T: 1.866.508.1118 | www.novaerus.com

Document No. 610-00-0319 Rev H. COPYRIGHT © 2019 NOVAERUS US, INC.