

DIGITAL TO ANALOG AUDIO CONVERTER

CREST
HEALTHCARE®

Introduction

This Digital to Analog Audio Converter is designed for either home or professional audio switching. It converts Coaxial or Toslink digital audio signals to analog L/R audio and available for connection to an external device such as an amplifier via standard RCA-style jacks.

This Converter has many features that enable it to perform in a superior manner.

Product feature

1. Converts Coaxial or Toslink digital audio signals to analog L/R audio、3.5mm audio output synchronously
2. Supports sampling rate at 32, 44.1, 48 and 96 KHz;
3. 24-bit S/PDIF incoming bit stream on left and right channels;
4. Provides electromagnetic-noise-free transmission
5. Easy to install and simple to operate.

Product specifications

- Input Audio: Coaxial or Toslink digital audio
- Output Audio: L/R audio、3.5mm audio jack
 - Input audio connector: Toslink、1XRCA(Coaxial)
 - Output audio connector: 2XRCAJR/LJ、
 - Sampling rate: 32, 44.1, 48 and 96 Khz
 - Power adapter: DC 5V

[1]

Environmental requirement

Operating temperature: -45°C to +80°C
Operating humidity: 10% to 85% (noncondensing)
Storage Temperature: -45°C to +80°C
Storage humidity: 5% to 90% (noncondensing)

Connection diagram



Package contents



Before attempting to use this device, please check the packaging and make sure the following items are contained in the package.

1. Converter 1 pc
2. DC 5V power adapter 1 pc
3. User's manual 1 pc

[2]