



BE PROTECTED IN MINUTES

The #1 cause of structure fires in the U.S. is cooking! These fires are responsible for an average of 1 billion dollars in damage each year. FireAvert helps mitigate your risk of having a kitchen fire. Simply plug FireAvert in behind the stove and sync it to the nearest smoke alarm. In the event the smoke alarm sounds due to the stove/oven, FireAvert will cut power, eliminating the heat source to prevent a kitchen fire! [See video below.](#)



3 PRONG | FA-E01-10-50

FEATURES

- Works with any smoke detector sound
- No batteries and maintenance free
- No professional install needed
- Fits in the void space behind most electric stoves
- Electrical Current Detection causes activation only when stove is on and smoke alarm sounds
- Reusable with a 25 year expected life.
- Resets at the electrical panel
- 3 and 4 prong configurations available
- Audible indication of sync with smoke alarm
- Light indicates number of times activated
- Sound detection of smoke alarm from up to 60 feet.

INSTALLATION PROCESS

FireAvert is plug-n-play ready. Simply plug into the back of the stove and sync it to the closest smoke alarm. FireAvert is activated by the smoke alarm, cutting power to the stove and oven when the smoke alarm is sounding. To reset the stove after it cuts off power simply flip the stove breaker off and then back on again. This will enable your stove to begin working again.

SEE HOW EASY IT IS TO INSTALL



FEEL FREE TO CONTACT A MEMBER OF OUR TEAM FOR QUESTIONS

Sales

Tyson Bell
Tyson@fireavert.com
801.692.0306

Accounting

Katie Wright:
Katie@fireavert.com
800.677.9870

Customer support

Kelson Wheeler
Kelson@fireavert.com
801.845.3075

ELECTRICAL SPECIFICATIONS

Operating Voltage	125/250v
Amperage	50 amps 60Hz
Plug Configuration	NEMA 14-50 R/P
Pole	3
Wire	4 wire grounding
Fire Rating	Housing ABS fire retardant - UL94(5Va,V-0,V-1,V-2,HB)

PHYSICAL SPECIFICATIONS

Master Carton Dimensions	14 inches wide x 18 inches high x 22.5 inches long
Master Carton Weight	55 lbs
Dimensions	7 ¾ inches (20 cm) x 2 ½ inches (6.35 cm) x 3 5/8 inches (9.2 cm) – (LxWxH)
Weight	1 ½ LB (0.68 Kg)
Color	Black
Operating Temperature Range	32°F to 90°F (0°C to 33°C)
Operating Humidity Range	0 to 80% RH non-compensating
Mounting	None required. Plugs directly into NEMA 14-50R outlet for electrical
Stove/Ranges	
Environmental	RY PB Free

LED MODES

LED Mode	Green LED	Red LED	Speaker
Power Up	Solid Green LED	Intermittent Red Flash	Intermittent Chirping
Syncing	Solid Green LED	Blinks Red	Off Once Synced
Standby	Solid Green LED	Off	Off
Protection Mode	Off	Solid	Off

WARRANTY

[CLICK HERE](#) to download the FireAvert Warranty