

Patient Stations, Crest Replacements for Rauland® Responder® III+



P/N BS800C (Single Stainless Steel Faceplate)
BS800CPL (Single Plastic Faceplate)
BS300C (Single Stainless Steel Faceplate)

BS810C (Single Stainless Steel Faceplate)
BS820C (Single Stainless Steel Faceplate)



BS800C

BS810C

BS820C

BS300C

Technical Specifications

ELECTRICAL

Voltage Rating:

12 - 14 VDC @ 20 MA

MECHANICAL

Terminals:

Wire Leads

Mounting:

Fits on standard single gang back box

SIZE MEASUREMENTS

Plate:

4.5" x 2.75" (Single Gang)

Wire Color Comparison Table

BS800C

	Rauland® Wire Color	Crest Wire Color
1	Black	Black
2	Brown	Brown
3	Red	Red
4	Orange	Orange
5	Yellow	Yellow
6	Pink	Brown/White
7	Blue	Blue
8	Purple	Purple
9	White	White
10	Grey	Grey
11	Black	Black

BS820C and BS810C

	Rauland® Wire Color	Crest Wire Color
1	Black	Black
2	Brown	Brown
3	Red	Red
4	Orange	Orange
5	Yellow	Yellow
6	Pink	Brown/White
7	Blue	Blue
8	Purple	Purple
9	Grey	Grey
10	White	White
11	Black	Black

BS820C, BS810C and BS300C

	Rauland® Wire Color	Crest Wire Color
1	Black	Black
2	Brown	Brown
3	Red	Red
4	Orange	Orange
5	Yellow	Yellow
6	Pink	Brown/White
7	Blue	Blue
8	Purple	Purple
9	N/A	Empty
10	N/A	Empty

Typical Installation

1. Replace existing station with Crest replacement, referencing the wire color comparison tables shown above
2. Always test all nurse call stations for correct operation (including cord out if applicable) before placing into service

Crest Technical Support: **1-800-328-8908**

Specifications subject to change without notice.

Visit CrestHealthcare.com for additional technical documents.