ProBeam BU60PST Laser Projector

Incredibly Bright and High Detailed Images

4K UHD resolution (3,840 x 2,160) 6,000 lumens brightness Mercury Free Laser (up to 20,000 hr. life) No Lamp - Virtually maintenance-free operation Wireless & Bluetooth Connection & webOS™ 4.5 12 Point Display Warping Control



Business Solutions

The LG ProBeam BU60PST laser projector delivers highly detailed images for critical government, financial, engineering, medical and digital signage installations in medium to large-sized spaces. This compact and quiet projector is designed for both install and table top usage. It provides 6000 lumens of brightness, more than 20,000 hours of laser life, lens shift and 1.6x optical zoom, HDBaseT[™] connectivity and a plethora of other features. The LG ProBeam BU60PST is also TAA compliant.

4K Ultra High Definition Resolution

The LG ProBeam BU60PST delivers a truly immersive experience with an incredible 8.3 million pixels (3840 x 1260) utilizing XPR technology based on TI DLP® technology.



Smart Connection

This projector provides convenient wireless functionality for collaborative meetings such as screen sharing through wireless mirroring and Bluetooth sound out. You can also browse the internet through the webOS 4.5 web browser.

6,000 Lumens Brightness

The LG ProBeam BU60PST provides brightness that delivers sharp and clear images regardless of external lighting. With 6000 lumens and HDR10 picture quality, viewers can experience vivid and immersive experiences.



20,000 Lifetime Hours


The LG ProBeam BU60PST projector uses a powerful laser diode that displays bright images and lasts up to 20,000 hours. If you play videos on this projector 8 hours a day, then the laser diode would last for 7 years. No more replacing expensive projector bulbs!

ProBeam BU60PST Laser Projector


PROJECTION SYSTEM	Display Type	DLP	AUDIO	Bluetooth sound out	Yes
	Native Resolution	4K UHD (3840 x 2160)*		Built-in Speakers	10W (5W+5W Stereo)
	4K Upscaling / Super Resolution	Yes		Bluetooth AV Sync Adjustment	Yes
	Screen Size	40" ~ 300"	INPUTS / OUTPUTS	Audio out	1 (Φ3.5)
	Projection Image	100"@9.4~15.2ft		HDMI™	2
	Aspect Ratio	16:9/Original/4:3/Vertical Zoom All-Direction Zoom		USB Type A RS-232C	2 (USB2.0) Yes
	Zoom	1.6x		RJ45	1 (HDBaseT)
	Lens Shift	Horiz ± 20% Vert ± 50%		HID	Yes (Keyboard/Mouse/GamePad Connection Thru USB)
	Brightness	Up to 6000 ANSI Lumens**		IP Control	Yes
	Contrast Ratio	3,000,000:1	POWER	Power Supply	100V – 240V @ 50~60 Hz (PSU
	Lamp Type	Laser (LD + P/W)		(Voltage/Hz)	Built-in)
	Lamp Life	Up to 20,000 Hrs		Power Consumption	440 W
	Noise (Economic / Normal / High brightness)	29 / 30 / 33 dB(A)		Standby Mode	<0.5W
			ACCESSORIES / MANUAL	Remote Control	1 Standard (Battery included)
				Manual	Simple Book
	HDCP	HDCP2.2		Warranty Card	Yes
	Trumotion	Yes		Power Cord	Yes
	HDR	HDR10	DIMENSIONS / WEIGHT	Product Dimensions	14.6" x 6.1" x 12.8"
	Digital Keystone Correction	Advanced Edge Adjustment (12 Point Warping)		Product Dimensions excluding lens & legs	14.6" x 5.7" x 11.4"
LG SMART TV	Web Browser	Yes		Shipping Dimensions	22.8" x 10.7" x 17.4"
CONNECTIVITY / WIRELESS	Bluetooth (with Speaker)	Yes		(WxHxĎ) Weight	21.4 lbs
	Screen Share	Yes		Shipping Weight	25.4 lbs
		(with Miracast supporting device)	WARRANTY / UPC	Limited Warranty	3 Years
	Wireless Contents Share	Yes (with iOS, Adroid via TV Plus App, with DLNA supporting device)		UPC	1 95174 00945 1

* 4K UHD resolution with 8.3 million discrete pixels projected by XPR (Expanded Pixel Resolution) video processing

** The Brightness is based on the perceived brightness equivelant to the brightness of lamp projector



Connectivity



https://www.lg.com/us/business/commercial-display

https://www.twitter.com/LGCommDisplays

f https://www.facebook.com/LGcommercialdisplays

https://www.linkedin.com/company/lg-commercial-displays-usa
https://www.youtube.com/lgcommercialdisplayusa
800.897.8726

Copyright 2021 [®]LG Electronics USA, Inc., 2000 Millbrook Drive Lincolnshire, IL 60069, USA. All rights reserved. LG and the LG logo are registered trademarks of LG Cop. All other products and brand names are trademarks or registered trademarks of their respective companies. Designs, features, and specifications are subject to change without notice. All screen images are simulated. LGE 042171 SPEC_BLGOPST_042171_LR



Business Solutions