

Product Indication Light

Product Code: ILB-21

Description: Easy install indication light provides a visual and audible alert for alarms inside the room; can forward wireless signals using LoRa to extend range

Features:

- Dual colored indication light for standard (Red) and bathroom (White) alarm events
- Buzzer with adjustable volume
- LoRa signal bump to greatly extend range to central monitor for call points and mobile devices
- Programmable group reset option
- Memory capacity for 16 devices
- Battery back-up in case of power loss
- Low battery and signal lost detection
- Designed according to BS 8300-2:2018 guidance for barrier free entry

Works with:

- WCP-11 Bathroom Call Point
- WCP-11C Bedhead Call Point
- DON-30 Receiver Dongle
- TM-11 Pad Transmitter Module
- TXP-11 Emergency Transmitter w/ Man-down
- NGM-21 CordFree Bed Monitor
- DMS-02 DoorWatcher Sensor
- AC-04 Power Adapter



Technical Specifications

Operating frequency: 433MHz, 435MHz (LoRa)
Operating range: 50m (line of sight), >1km (LoRa)
Power supply: 12V DC, 800mA
or 6 x C-type alkaline batteries
Battery life: 2-3 years standby
Dimensions: 16 x 11 x 6cm (case)
Housing material: ABS
Net weight: ~300g (without batteries)
Operating temp.: 5°C ~ 40°C
Rel. humidity: < 85%

Standards

EMC: EN 55022
Radio: EN 300220-1&2,
EN 301489-1&3
Alarm: EN 50130-4
Safety: EN 60950-1
Manufacture: ISO 9001:2008,
ISO 13485:2003
Barrier Free: BS8 300-2:2018
FCC WNG-ILB-21