

# SF530UL Single Resident Bed Station

## IL830 Specification Sheet

Tek-CARE®500 Wireless Nurse Call System • Rev. 6 - 11/2016

### Features

- UL® 2560 Listed
- Fully supervised wireless 900MHz transmitter
- Provides standard ¼" receptacle, suitable for use with many call cord types
- Checks for cord out state
- Low battery warning before battery depletion
- Call assurance LED
- Field replaceable 3V lithium battery

### Description

The SF530UL single resident bed station features the great range and reliability of 900MHz signaling. This unit can be wall mounted near any resident location for call placement. It provides a standard ¼" call cord receptacle along with a reset button. Calls are latched locally to ensure that residents receive direct staff attention. The device includes a call assurance LED as well as cord out detection. The SF530UL features a fully supervised RF link to ensure reliability and to monitor for battery low condition. The battery is a customer replaceable 3V lithium.

### Specifications

Dimensions:	Height:	4.5"	(114.3 mm)
	Width:	2.8125"	(71.4 mm)
	Overall Depth:	2.35"	(59.7 mm)
	Projects Front:	0.4375"	(11.1 mm)
	Projects Rear:	1.9125"	(48.6 mm)
Construction:	Flame-retardant (UL® 94V-0) plastic		
Flush Housing:	Plastic single-gang box with minimum 2.875" x 2.125" opening		
Surface Housing:	TekTone® IH527 plastic back box		
Battery:	3.0V Lithium (BA505)		



**SF530UL Single Resident Bed Station**

### Listings



UL® 2560 Listed; UL® File Number E71599.

### Required Components

Tek-CARE®500 Wireless Nurse Call System

TekTone® has designed Tek-CARE®500 to work as a system. Its Tek-BRIDGE® Server has been carefully designed and matched to work with Tek-CARE500 wireless and wired peripherals. TekTone will not warrant or support components of Tek-CARE500 that are purchased separately unless the components are add-ons to previously sold systems. TekTone will also not warrant or support a system that is a mix of TekTone and Non-TekTone parts, unless prior permission has been obtained. A site survey must be performed and submitted before ordering a Tek-CARE500 system. In order to track our systems and to inform facilities of software upgrades, full site information (site name, address and phone number) will be required when ordering. Site information and Tek-BRIDGE Server warranty numbers will also be required when requesting technical support.

[www.tektone.com](http://www.tektone.com)

324 Industrial Park Road • Franklin, NC 28734 • [tektone@tektone.net](mailto:tektone@tektone.net)

Phone: 828.524.9967 • Fax: 828.524.9968 • Sales: Choose option 2 • Tech Support: Choose option 3

**TekTone's quality system is registered by DQS to the ISO 9001 standard. (Reference #10001510.)**